

**LOK-ITT COLUMN LOCK APPLICATION GUIDE**

**GENERAL MOTORS**

**Oldsmobile**

Vehicle Make/Model -(1)		Year	Model #	Airbag Protector
<b>Automobiles</b>	<b>Calais</b>	1984-1989	<b>P300</b>	AB100
	<b>Ciera</b>	1978-1993	<b>P300</b> ❖	AB100
	<b>Custom Cruiser</b>	1978-1996	<b>P300</b> ❖	AB100
	<b>Cutlass Supreme</b>	1970-1977	<b>P301</b>	AB100
		1978-1987	<b>P300</b> ❖	AB100
		1988-1993	<b>600</b>	NA
	<b>Delta 88</b>	1970-1977	<b>P301</b>	AB100
		1978-1993	<b>P300</b> ❖	AB100
	<b>Delta 88 Royale</b>	1994	<b>P302</b>	AB100
	<b>Firenza</b>	1984-1988	<b>P302</b>	AB100
	<b>Ninety Eight</b>	1970-1977	<b>P301</b>	AB100
		1978-1993	<b>P300</b> ❖	AB100
	<b>Toronado</b>	1970-1977	<b>P301</b>	AB100
	1978-1985	<b>P300</b>	AB100	
<b>Sport Utility</b>	<b>Bravada</b>	1995-1997	<b>P250</b>	AB100
		1998	<b>NA</b>	NA
		1999-2001	<b>P250</b>	AB100
	<b>Silhouette</b>	1988-1993	<b>P300</b>	AB100
		1997-2001	<b>P250</b>	AB100